

Borehole Extensometer


Purpose

To monitor sub-surface settlement indicating the total settlement as well as the incremental settlement at the depth of each magnet.


Application

Monitor settlement or heave in excavations, foundations, and embankments.

Monitor settlement or heave above tunnels and other underground openings.



Overview of the magnetic extensometer



Magnetic extensometer