

EL Tiltmeter

Purpose

To monitor changes in the tilt of a structure by electronic means.

Application

1. Monitor changes in the tilt of a structure.

Changes in tilt can occur when nearby construction activity affects the ground that supports the structure.

Activities such as excavation, tunneling, or dewatering may cause settlement or lateral deformation.

Changes in tilt are also caused when a load is applied to a structure.

2. Monitor rotation or angular distortion of columns, walls and beams caused by tunneling , excavation or soil compaction works.



EL Tiltmeter



EL Tiltmeter installed on column



EL Tiltmeter installed on columns at client's office